

# SECTION AX

GI

MA

EM

LC

EC

FE

CL

MT

AT

**AX**

SU

BR

ST

RS

BT

HA

SC

EL


IDX

## CONTENTS

<b>FRONT AXLE</b> .....	2	INSTALLATION.....	12
Precautions .....	2	DISASSEMBLY.....	13
PRECAUTIONS .....	2	INSPECTION.....	15
Preparation .....	2	ASSEMBLY .....	15
SPECIAL SERVICE TOOLS .....	2	<b>REAR AXLE</b> .....	20
COMMERCIAL SERVICE TOOLS.....	2	Precautions .....	20
Noise, Vibration and Harshness (NVH)		PRECAUTIONS .....	20
Troubleshooting .....	3	Preparation .....	20
NVH TROUBLESHOOTING CHART .....	3	COMMERCIAL SERVICE TOOLS.....	20
On-vehicle Service.....	3	Noise, Vibration and Harshness (NVH)	
FRONT AXLE PARTS .....	3	Troubleshooting .....	20
FRONT WHEEL BEARING .....	4	On-vehicle Service.....	20
DRIVE SHAFT .....	4	REAR AXLE PARTS.....	20
Wheel Hub and Knuckle.....	5	REAR WHEEL BEARING .....	21
COMPONENTS .....	5	Wheel Hub.....	21
REMOVAL.....	5	COMPONENTS .....	21
INSTALLATION.....	6	REMOVAL.....	21
DISASSEMBLY.....	7	INSTALLATION.....	22
INSPECTION.....	8	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	23
ASSEMBLY .....	8	Drive Shaft.....	23
Drive Shaft.....	10	Wheel Bearing (Front) .....	23
COMPONENTS .....	10	Wheel Bearing (Rear).....	23
REMOVAL.....	11		

# FRONT AXLE

## Precautions



## Precautions PRECAUTIONS

- When installing rubber parts, final tightening must be carried out under unladen condition\* with tires on ground.  
\*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Use flare nut wrench when removing or installing brake tubes.
- Always torque brake lines when installing.



NCAX0001

## Preparation

## SPECIAL SERVICE TOOLS


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

NCAX0002

Tool number (Kent-Moore No.) Tool name	Description
HT72520000 (J25730-B) Ball joint remover	 Removing tie-rod outer end and lower ball joint NT146
KV38106700 (J34296) KV38106800 (J34297) Differential side oil seal protector	 Installing drive shaft LH: KV38106700 (J34296) RH: KV38106800 (J34297) NT147

## COMMERCIAL SERVICE TOOLS

NCAX0003

Tool name	Description
1 Flare nut crowfoot 2 Torque wrench	 Removing and installing each brake piping a: 10 mm (0.39 in) NT360

# FRONT AXLE

Noise, Vibration and Harshness (NVH) Troubleshooting

## Noise, Vibration and Harshness (NVH) Troubleshooting

=NCAx0004


NCAx0004S01

### NVH TROUBLESHOOTING CHART

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Reference page			—	AX-15	—	AX-5, 21	—	AX-4, 21	Refer to DRIVE SHAFT in this chart.	Refer to AXLE in this chart.	NVH in SU section	NVH in SU section	NVH in SU section	NVH in BR section	NVH in ST section	
Possible cause and SUSPECTED PARTS			Excessive joint angle	Joint sliding resistance	Imbalance	Improper installation, looseness	Parts interference	Wheel bearing damage	DRIVE SHAFT	AXLE	SUSPENSION	TIRES	ROAD WHEEL	BRAKES	STEERING	
Symptom	DRIVE SHAFT	Noise, Vibration	x	x						x	x	x	x	x	x	
		Shake	x		x					x	x	x	x	x	x	
	AXLE	Noise				x	x		x		x	x	x	x	x	x
		Shake				x	x		x		x	x	x	x	x	x
		Vibration				x	x		x		x	x				x
		Shimmy				x	x				x	x	x	x	x	x
		Judder				x					x	x	x	x	x	x
Poor quality ride or handling				x	x	x				x	x	x				

x: Applicable



### On-vehicle Service

#### FRONT AXLE PARTS

NCAx0005

Check front axle and front suspension parts for excessive play, cracks, wear or other damage.


- Shake each front wheel to check for excessive play.
- Make sure that cotter pin is inserted.
- Retighten all axle and suspension nuts and bolts to the specified torque.

**Tightening torque:**

Refer to "FRONT SUSPENSION", in SU section.

# FRONT AXLE

On-vehicle Service (Cont'd)



## FRONT WHEEL BEARING

NCAx0006


- Check that wheel bearings operate smoothly.
- Check axial end play.

### Axial end play:

**0.05 mm (0.0020 in) or less**

If out of specification or wheel bearing does not turn smoothly, replace wheel bearing assembly.

Refer to "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.



## DRIVE SHAFT


NCAx0007

Check for grease leakage or other damage.

## Wheel Hub and Knuckle COMPONENTS

=NCAX0008

SEC. 400



1. Drive shaft
2. Inner grease seal
3. Snap ring
4. Knuckle
5. Baffle plate
6. Wheel bearing assembly

7. Snap ring
8. Outer grease seal
9. Hub bolt
10. Wheel hub
11. Plain washer

12. Wheel bearing lock nut
13. Cotter pin
14. Brake disc
15. Wheel nut
16. ABS sensor

### REMOVAL

#### CAUTION:

Before removing the front axle assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the front axle assembly area.


Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.

1. Remove wheel bearing lock nut.

NCAX0009

# FRONT AXLE


## Wheel Hub and Knuckle (Cont'd)



2. Remove brake caliper assembly and rotor.

**Brake hose need not be disconnected from brake caliper. In this case, suspend caliper assembly with wire so as not to stretch brake hose. Be careful not to depress brake pedal, or piston will pop out.**


**Make sure brake hose is not twisted.**



3. Separate tie-rod from knuckle with Tool.


**Install stud nut on stud bolt to prevent damage to stud bolt.**

4. Remove kingpin cap and securing nut. Separate kingpin from knuckle.



5. Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.


**Cover boots with shop towel so as not to damage them when removing drive shaft.**



6. Loosen lower ball joint tightening nut.

7. Separate knuckle from lower ball joint stud with Tool.

8. Remove knuckle from transverse link.



## INSTALLATION

1. Install knuckle with wheel hub.

2. Tighten wheel bearing lock nut.


 : 235 - 314 N·m (24 - 32 kg·m, 174 - 231 ft·lb)

3. Check that wheel bearings operate smoothly.

NCAX0010

# FRONT AXLE

Wheel Hub and Knuckle (Cont'd)



4. Check wheel bearing axial end play.


**Axial end play:**  
0.05 mm (0.0020 in) or less

GI

MA

EM

LC



## DISASSEMBLY

NCA0011

### CAUTION:

When removing wheel hub or wheel bearing from knuckle, replace wheel bearing assembly (outer race, inner races and grease seals) with a new one.

EC

FE


### Wheel Hub

NCA0011S01

Drive out hub with inner race (outside) from knuckle with a suitable tool.

CL

MT



### Wheel Bearing

NCA0011S02

When replacing wheel bearing, replace complete wheel bearing assembly (Inner races and outer race).


AT

1. Remove bearing inner race (outside), then remove outer grease seal.

AX

SU

BR




2. Remove inner grease seal from knuckle.

ST

RS

BT

HA



3. Remove snap rings.


SC

EL

IDX

# FRONT AXLE

## Wheel Hub and Knuckle (Cont'd)



4. Press out bearing outer race.

## INSPECTION

### Wheel Hub and Knuckle

Check wheel hub and knuckle for cracks by using a magnetic exploration or dyeing test.


### Snap Ring

Check snap ring for wear or cracks. Replace if necessary.

NCAAX0012

NCAAX0012S01

NCAAX0012S02



## ASSEMBLY

1. Install inner snap ring into groove of knuckle.
2. Press new wheel bearing assembly into knuckle until it contacts snap ring.

**Maximum load P:**


**49 kN (5 ton, 5.5 US ton, 4.9 Imp ton)**

### CAUTION:

- Do not press inner race of wheel bearing assembly.
- Do not apply oil or grease to mating surfaces of wheel bearing outer race and knuckle.

3. Install outer snap ring into groove of knuckle.


NCAAX0013




4. Pack grease seal lip with multi-purpose grease.
5. Install outer grease seal.

# FRONT AXLE

Wheel Hub and Knuckle (Cont'd)



6. Install inner grease seal.




7. Press wheel hub into knuckle.

**Maximum load P:**

**49 kN (5 ton, 5.5 US ton, 4.9 Imp ton)**

**Be careful not to damage grease seal.**




8. Check bearing operation.

a. Add load P with press.

**Load P:**

**34.3 - 49.0 kN**

**(3.5 - 5.0 ton, 3.9 - 5.5 US ton, 3.44 - 4.92 Imp ton)**



b. Spin knuckle several turns in both directions.

c. Make sure that wheel bearings operate smoothly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# FRONT AXLE

Drive Shaft

## Drive Shaft COMPONENTS


NCAX0016

### SEC. 391

Circular clip:

Circular clips should be properly meshed with differential side gear (transaxle side) and with joint assembly (wheel side). Make sure they will not come out.

**Be careful not to damage boots. Use suitable protector or cloth during removal and installation.**



: N·m (kg·m, ft·lb)

Transaxle side (DS83)

Right drive shaft

SFA712BB

- |                        |                         |  |
|------------------------|-------------------------|--|
| 1. Dust shield         | 10. Boot                | 19. Circular clip                            |
| 2. ABS ring            | 11. Boot band           | 20. Slide joint housing with extension shaft |
| 3. Joint assembly      | 12. Stopper ring        | 21. Dust shield                              |
| 4. Boot                | 13. Inner race          | 22. Snap ring                                |
| 5. Boot band           | 14. Cage                | 23. Support bearing                          |
| 6. Circular clip       | 15. Ball                | 24. Support bearing retainer                 |
| 7. Drive shaft         | 16. Snap ring           | 25. Bracket                                  |
| 8. Dynamic damper      | 17. Slide joint housing | 26. Snap ring                                |
| 9. Dynamic damper band | 18. Dust shield         | 27. Dust shield                              |

# FRONT AXLE


Drive Shaft (Cont'd)

## SEC. 391

Circular clip:

Circular clips should be properly meshed with differential side gear (transaxle side) and with joint assembly (wheel side). Make sure they will not come out.

**Be careful not to damage boots. Use suitable protector or cloth during removal and installation.**




SFA589BC

- |                   |                        |                         |
|-------------------|------------------------|-------------------------|
| 1. Dust shield    | 7. Drive shaft         | 12. Spider assembly     |
| 2. ABS ring       | 8. Dynamic damper      | 13. Snap ring           |
| 3. Joint assembly | 9. Dynamic damper band | 14. Slide joint housing |
| 4. Boot           | 10. Boot               | 15. Dust shield         |
| 5. Boot band      | 11. Boot band          | 16. Circular clip       |

## REMOVAL

NCAAX0014


1. Remove wheel bearing lock nut.
2. Remove brake caliper assembly and rotor.  
**Brake hose need not be disconnected from brake caliper. In this case, suspend caliper assembly with wire so as not to stretch brake hose.**  
**Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.**
3. Remove tie-rod ball joint.
4. Remove upper knuckle nut.
5. Separate drive shaft from knuckle by lightly tapping it. If it is hard to remove, use a puller.  
**Cover boots with shop towel so as not to damage them when removing drive shaft.**  
Refer to "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.
6. Remove right drive shaft from transaxle.



SFA989

# FRONT AXLE


## Drive Shaft (Cont'd)



7. Remove left drive shaft from transaxle.

— For M/T models —


- Pry off drive shaft from transaxle as shown at left.



— For A/T models —

- Insert screwdriver into transaxle opening for right drive shaft and strike with a hammer.

**Be careful not to damage pinion mate shaft and side gear.**



## INSTALLATION


### Transaxle Side

NCAX0015

NCAX0015S01

1. Drive a new oil seal to transaxle. Refer to MT or AT section "Replacing Oil Seal" or "Differential Side Oil Seal Replacement", "ON-VEHICLE SERVICE".

2. Set Tool along the inner circumference of oil seal.



3. Insert drive shaft into transaxle. Be sure to properly align the serrations and then withdraw Tool.

4. Push drive shaft, then press-fit circular clip on the drive shaft into circular clip groove of side gear.

5. After its insertion, try to pull the flange out of the slide joint by hand. If it pulls out, the circular clip is not properly meshed with the side gear.

## Wheel Side

NCAx0015S02


- Install drive shaft into knuckle.
- Tighten upper knuckle nut and wheel bearing lock nut. Refer to section Installation in "Wheel Hub and Knuckle", "FRONT AXLE", AX-5.

GI

MA

EM

LC



SFA476

## DISASSEMBLY

### Transaxle Side

NCAx0017

#### (DS83 type)

NCAx0017S01

NCAx0017S0101


1. Remove boot bands.
2. Put matching marks on slide joint housing and inner race, before separating joint assembly.
3. Remove stopper ring with a screwdriver, and pull out slide joint housing.

EC

FE

CL

MT



SFA514A

4. Put matching marks on inner race and drive shaft.
5. Remove snap ring, then remove ball cage, inner race and balls as a unit.
6. Draw out boot.


AT

AX

**Cover drive shaft serrations with tape so as not to damage the boot.**

SU

BR



SFA963

#### (TS83 type)

NCAx0017S0102


1. Remove boot bands.
2. Put matching marks on slide joint housing and drive shaft before separating joint assembly.
3. Put matching marks on spider assembly and drive shaft.

ST

RS

BT

HA



SFA612

4. Remove snap ring, then remove spider assembly.

SC

#### CAUTION:

**Do not disassemble spider assembly.**

EL


5. Draw out boot.

**Cover drive shaft serration with tape to prevent damage to the boot.**

IDX

# FRONT AXLE

## Drive Shaft (Cont'd)



### Wheel Side (BF86 type)

NCA0017S02


#### CAUTION:

The joint on the wheel side cannot be disassembled.

1. Before separating joint assembly, put matching marks on drive shaft and joint assembly.
2. Separate joint assembly with a suitable tool.

Be careful not to damage threads on drive shaft.


3. Remove boot bands.
4. Draw out boot.




### Support Bearing

NCA0017S03


1. Remove dust shield.



2. Remove snap ring.



3. Press support bearing assembly off of drive shaft.



4. Separate support bearing from retainer.

## INSPECTION

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

NCAx0018

GI

### Drive Shaft

Replace drive shaft if it is twisted or cracked.

NCAx0018S01

MA

### Boot

Check boot for fatigue, cracks or wear. Replace boot with new boot bands.

NCAx0018S02

EM

### Joint Assembly (Transaxle side)

- Check spider assembly for needle bearing and washer damage. Replace if necessary. (TS83 type)
- Check roller surfaces for scratches, wear or other damage. Replace if necessary. (TS83 type)
- Replace any parts of double offset joint which show signs of scorching, rust, wear or excessive play. (DS83 type)
- Check serration for deformation. Replace if necessary.
- Check slide joint housing for any damage. Replace if necessary.

NCAx0018S03

LC

EC

FE

CL

### Joint Assembly (Wheel side)

Replace joint assembly if it is deformed or damaged.

NCAx0018S04

MT

### Support Bearing

Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.

NCAx0018S05

AT

### Support Bearing Bracket

Check support bearing bracket for cracks with a magnetic exploration or dyeing test.

NCAx0018S06

AX

SU

## ASSEMBLY

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use NISSAN GENUINE GREASE or equivalent after every overhaul.

NCAx0019

BR


ST

RS

BT

HA

SC



### Wheel Side (BF86 type)

1. Install boot and new small boot band on drive shaft.

NCAx0019S01





Cover drive shaft serration with tape so as not to damage boot during installation.

EL

IDX

# FRONT AXLE

## Drive Shaft (Cont'd)



2. Set joint assembly onto drive shaft by lightly tapping it. Install joint assembly securely, ensuring marks which were made during disassembly are properly aligned.

3. Pack drive shaft with specified amount of grease.

**Specified amount of grease:**

**95 - 115 g (3.35 - 4.06 oz)**

4. Make sure that boot is properly installed on the drive shaft groove. Set boot so that it does not swell and deform when its length is "L<sub>1</sub>".

**Length "L<sub>1</sub>":**

**100.5 mm (3.96 in)**

5. Lock new larger and smaller boot bands securely with a suitable tool.

## Dynamic Damper


NCAx0019S02

1. Use new damper bands when installing.
2. Install dynamic damper from stationary-joint side while holding it securely.

### Length:

Unit: mm (in)

Applied model	RH		LH		BF86/TS83
	BF86/DS83 + B		BF86/DS83		
Transaxle	Without viscous type	With viscous type	With viscous type		Without viscous type
			M/T	A/T	
"A"	205.1 (8.07)	186.0 (7.32)	163.5 (6.44)	157.8 (6.21)	181.0 (7.13)
"B"	70 (2.76)				




## Transaxle Side (DS83 type)

NCAAX0019S03


NCAAX0019S0301

1. Install boot and new small boot band on drive shaft.

**Cover drive shaft serration with tape so as not to damage boot during installation.**



2. Install ball cage, inner race and balls as a unit, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring.



4. Pack drive shaft with specified amount of grease.


**Specified amount of grease:**

**115 - 135 g (4.06 - 4.76 oz)**


5. Install slide joint housing, then install new snap ring.
6. Make sure that boot is properly installed on the drive shaft groove.  
Set boot so that it does not swell and deform when its length is "L<sub>2</sub>".

**Length "L<sub>2</sub>":**

**98 mm (3.86 in)**



7. Lock new larger and smaller boot bands securely with a suitable tool.



## (TS83 type)

NCAAX0019S0302

1. Install boot and new small boot band on drive shaft.

**Cover drive shaft serration with tape to prevent damage to boot during installation.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

# FRONT AXLE

## Drive Shaft (Cont'd)




2. Install spider assembly securely, making sure the marks which were made during disassembly are properly aligned.
3. Install new snap ring.




4. Pack drive shaft with specified amount of grease.  
**Specified amount of grease:**  
 125 - 145 g (4.41 - 5.11 oz)
5. Install slide joint housing.
6. Set boot so that it does not swell and deform when its length is "L<sub>2</sub>".  
**Length "L<sub>2</sub>":**  
 99 mm (3.90 in)

**Make sure that boot is properly installed on the drive shaft groove.**




7. Lock new larger and smaller boot bands securely with a suitable tool.



### Support Bearing

NCAX0019S04


- Press bearing into retainer.



- Press drive shaft into bearing.

# FRONT AXLE

Drive Shaft (Cont'd)



- Install snap ring.
- Install new dust shield.

GI

MA

EM

LC

EC

FE

CL

MT

AT

**AX**

SU

BR

ST

RS

BT

HA


SC

EL

IDX

# REAR AXLE

## Precautions



## Precautions PRECAUTIONS

NCAx0022

- When installing each rubber part, final tightening must be carried out under unladen condition\* with tires on ground.  
\*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment.
- Do not jack up at the trailing arm and lateral link.
- Always torque brake lines when installing.

## Preparation

### COMMERCIAL SERVICE TOOLS


NCAx0024

Tool name	Description
GG94310000 1 Flare nut crowfoot 2 Torque wrench	<p>Removing and installing brake piping a: 10 mm (0.39 in)</p>

## Noise, Vibration and Harshness (NVH) Troubleshooting

NCAx0025

Refer to "Noise, Vibration and Harshness (NVH) Troubleshooting", "FRONT AXLE", AX-3.



## On-vehicle Service REAR AXLE PARTS


NCAx0026

Check axle and suspension parts for excessive play, wear or damage.

- Shake each rear wheel to check for excessive play.

# REAR AXLE

On-vehicle Service (Cont'd)



## REAR WHEEL BEARING


NCA0027

- Check axial end play.  
**Axial end play:**  
**0.05 mm (0.0020 in) or less**
- Check that wheel hub bearings operate smoothly.
- Check tightening torque of wheel bearing lock nut.  
**⌘ : 186 - 235 N·m (19 - 24 kg-m, 137 - 174 ft-lb)**
- Replace wheel bearing assembly if there is axial end play or wheel bearing does not turn smoothly. Refer to "Wheel Hub", "REAR AXLE", AX-21.

GI  
MA  
EM  
LC

## Wheel Hub COMPONENTS

NCA0028



EC  
FE  
CL  
MT  
AT  
**AX**  
SU  
BR  
ST  
RS  
BT

1. Spindle
2. Baffle plate
3. Wheel hub bearing

4. Wheel bearing lock nut
5. Cotter pin

6. Hub cap
7. ABS sensor

## REMOVAL

NCA0029

### CAUTION:


- Before removing the rear wheel hub assembly, disconnect the ABS wheel sensor from the assembly. Then move it away from the hub assembly. Failure to do so may result in damage to the sensor wires and the sensor becoming inoperative.
- Wheel hub bearing does not require maintenance. If any of the following symptoms are noted, replace wheel hub bearing assembly.

SC  
EL  
IDX

## REAR AXLE

### Wheel Hub (Cont'd)

- Growling noise is emitted from wheel hub bearing during operation.
- Wheel hub bearing drags or turns roughly. This occurs when turning hub by hand after bearing lock nut is tightened to specified torque.




1. Remove brake caliper assembly.
2. Remove wheel bearing lock nut.
3. Remove brake rotor.
4. Remove wheel hub bearing from spindle.

**Brake hose does not need to be disconnected from brake caliper.**

**Suspend caliper assembly with wire so as not to stretch brake hose.**


**Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.**



### INSTALLATION

NCA0030

- Install wheel hub bearing.
- Tighten wheel bearing lock nut. Before tightening, apply oil to threaded portion of rear spindle and both sides of plain washer.  
☑ : 186 - 235 N·m (19 - 24 kg-m, 137 - 174 ft-lb)
- Check that wheel bearings operate smoothly.



- Check wheel hub bearing axial end play.  
**Axial end play:**  
**0.05 mm (0.0020 in) or less**

# SERVICE DATA AND SPECIFICATIONS (SDS)


Drive Shaft

## Drive Shaft


NCAX0020

Applied model		RH		LH	
		Both		With viscous type	Without viscous type
Joint type	Transaxle side	DS83			TS83
	Wheel side	BF86			
Grease	Quality	Nissan genuine grease or equivalent			
	Capacity g (oz)	Transaxle side	115 - 135 (4.06 - 4.76)		125 - 145 (4.41 - 5.11)
		Wheel side	95 - 115 (3.35 - 4.06)		
Boot length mm (in)	Transaxle side "L <sub>2</sub> "	98 (3.86)		99 (3.90)	
	Wheel side "L <sub>1</sub> "	100.5 (3.96)			

Transaxle side



Wheel side



SFA961A

SFA962A

## Wheel Bearing (Front)

NCAX0021

Wheel bearing axial end play limit mm (in)	0.05 (0.0020) or less
Wheel bearing lock nut tightening torque N-m (kg-m, ft-lb)	235 - 314 (24 - 32, 174 - 231)

## Wheel Bearing (Rear)

NCAX0031

Wheel bearing axial end play mm (in)	0.05 (0.0020) or less
Wheel bearing lock nut tightening torque N-m (kg-m, ft-lb)	186 - 235 (19 - 24, 137 - 174)