

SECTION MA

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

CONTENTS

PRECAUTIONS	2	Changing Spark Plugs (Conventional type)	20
Precautions for Supplemental Restraint System (SRS) "AIR BAG"	2	Checking EVAP Vapor Lines	21
PREPARATION	3	CHASSIS AND BODY MAINTENANCE	22
Special Service Tool	3	Checking Exhaust System	22
Commercial Service Tool	3	Checking Clutch Fluid Level and Leaks	22
GENERAL MAINTENANCE	4	Checking M/T Oil	22
PERIODIC MAINTENANCE	6	Changing M/T Oil	22
Schedule 1	7	Checking A/T Fluid	23
EMISSION CONTROL SYSTEM MAINTENANCE	7	Changing A/T Fluid	23
CHASSIS AND BODY MAINTENANCE	8	Balancing Wheels	24
Schedule 2	9	Tire Rotation	24
EMISSION CONTROL SYSTEM MAINTENANCE	9	Checking Brake Fluid Level and Leaks	24
CHASSIS AND BODY MAINTENANCE	10	Checking Brake Lines and Cables	24
RECOMMENDED FLUIDS AND LUBRICANTS	11	Checking Disc Brake	24
Fluids and Lubricants	11	ROTOR	24
SAE Viscosity Number	11	CALIPER	25
GASOLINE ENGINE OIL	11	PAD	25
Anti-freeze Coolant Mixture Ratio	12	Checking Steering Gear and Linkage	25
ENGINE MAINTENANCE	13	STEERING GEAR	25
Checking Drive Belts	13	STEERING LINKAGE	25
Changing Engine Coolant	14	Checking Power Steering Fluid and Lines	25
—DRAINING ENGINE COOLANT—	14	CHECKING FLUID LEVEL	25
—REFILLING ENGINE COOLANT—	15	CHECKING LINES	25
—FLUSHING COOLING SYSTEM—	16	Lubricating Locks, Hinges and Hood Latches	26
Checking Fuel Lines	16	Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters	26
Changing Fuel Filter	16	SERVICE DATA AND SPECIFICATIONS (SDS)	27
Ⓜ WITH CONSULT	16	Engine Maintenance	27
Ⓧ WITHOUT CONSULT	17	DRIVE BELT DEFLECTION AND TENSION	27
Changing Air Cleaner Filter	17	SPARK PLUG TYPE	27
VISCIOUS PAPER TYPE	17	Chassis and Body Maintenance	27
Changing Engine Oil	17	WHEEL BALANCE	27
Changing Oil Filter	18		
Changing Spark Plugs (Platinum-tipped type)	19		

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) "AIR BAG"

Precautions for Supplemental Restraint System (SRS) "AIR BAG"

NCMA0001

The Supplemental Restraint System "AIR BAG", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. In addition to the supplemental air bags for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (which is one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (which is one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified with yellow harness protector or yellow insulation tape before the harness connectors.**


PREPARATION

Special Service Tool

Special Service Tool

NCMA0002

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10115801 (J38956) Oil filter cap wrench	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Removing oil filter a: 64.3 mm (2.531 in)</p> </div> </div> <p style="text-align: left; margin-top: 10px;">NT375</p>

GI


MA

EM

LC

Commercial Service Tool

NCMA0010

Tool name (Kent-Moore No.)	Description
Belt tension gauge (BT3373-F)	<div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p>Checking drive belt tension</p> </div> </div> <p style="text-align: left; margin-top: 10px;">AMA126</p>

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

GENERAL MAINTENANCE

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform checks and inspections themselves or they can have their INFINITI dealers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item		Reference page
Tires	Check the pressure with a gauge periodically when at a service station, including the spare, and adjust to the specified pressure if necessary. Check carefully for damage, cuts or excessive wear.	—
Wheel nuts	When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	—
Tire rotation	Tires should be rotated every 12,000 km (7,500 miles).	MA-24
Wheel alignment and balance	If the vehicle pulls to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	MA-24, "Front Wheel Alignment" in SU section
Windshield wiper blades	Check for cracks or wear if they do not wipe properly.	—
Doors and engine hood	Check that all doors and the engine hood operate smoothly as well as the trunk lid and back hatch. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-26

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item		Reference page
Lamps	Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check headlamp aim.	—
Warning lamps and buzzers/chimes	Make sure that all warning lamps and buzzers/chimes are operating properly.	—
Windshield wiper and washer	Check that the wipers and washer operate properly and that the wipers do not streak.	—
Windshield defroster	Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioning.	—
Steering wheel	Check that it has the specified play. Be sure to check for changes in the steering condition, such as excessive play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in)	—
Seats	Check seat position controls such as seat adjusters, seatback recliner, etc. to make sure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seatbacks.	—
Seat belts	Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-26 "Seat Belt Inspection" in RS section
Accelerator pedal	Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.	—

GENERAL MAINTENANCE

Item		Reference page	
Clutch pedal	Make sure the pedal operates smoothly and check that it has the proper free play.	"Adjusting Clutch Pedal" in CL section	GI
Brakes	Check that the brake does not pull the vehicle to one side when applied.	—	MA
Brake pedal and booster	Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Be sure to keep floor mats away from the pedal.	"Brake Pedal and Bracket" and "Brake Booster" in BR section	EM
Parking brake	Check that the lever has the proper travel and make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	"Parking Brake Control" in BR section	LC
Automatic transmission "Park" mechanism	Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that the vehicle is held securely with the selector lever in the "P" position without applying any brakes.	—	EC

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).

Item		Reference page	
Windshield washer fluid	Check that there is adequate fluid in the tank.	—	CL
Engine coolant level	Check the coolant level when the engine is cold.	MA-14	MT
Radiator and hoses	Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, deterioration or loose connections.	—	AT
Brake and clutch fluid levels	Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoir.	MA-22, 24	AX
Battery	Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines.	—	SU
Engine drive belts	Make sure that no belt is frayed, worn, cracked or oily.	MA-13	
Engine oil level	Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-17	BR
Power steering fluid level and lines	Check the level is between the "MAX" and "MIN" lines on the reservoir with the engine off. Check the lines for improper attachment, leaks, cracks, etc.	MA-25	ST
Automatic transmission fluid level	Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-23	RS
Exhaust system	Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-22	BT
Underbody	The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—	HA
Fluid leaks	Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	—	SC
			EL
			IDX

PERIODIC MAINTENANCE

Two different maintenance schedules are provided, and should be used, depending upon the conditions in which the vehicle is mainly operated. **After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage/time intervals.**

Schedule 1	Follow Periodic Maintenance Schedule 1 if your driving habits frequently includes one or more of the following driving conditions: <ul style="list-style-type: none"> ● Repeated short trips of less than 5 miles (8 km). ● Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing. ● Operating in hot weather in stop-and-go "rush hour" traffic. ● Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use. ● Driving in dusty conditions. ● Driving on rough, muddy, or salt spread roads. ● Towing a trailer, using a camper or a car-top carrier. 	Emission Control System Maintenance	MA-7
		Chassis and Body Maintenance	MA-8
Schedule 2	Follow Periodic Maintenance Schedule 2 if none of the driving conditions shown in Schedule 1 apply to your driving habits.	Emission Control System Maintenance	MA-9
		Chassis and Body Maintenance	MA-10

PERIODIC MAINTENANCE

Schedule 1

Schedule 1

EMISSION CONTROL SYSTEM MAINTENANCE

NCMA0004S01
NCMA0004S0101

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION	MAINTENANCE INTERVAL												Reference Section - Page or Content Title				
	3.75 (6) 3	7.5 (12) 6	11.25 (18) 9	15 (24) 12	18.75 (30) 15	22.5 (36) 18	26.25 (42) 21	30 (48) 24	33.75 (54) 27	37.5 (60) 30	41.25 (66) 33	45 (72) 36		48.75 (78) 39	52.5 (84) 42	56.25 (90) 45	60 (96) 48
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months																MA-13
Drive belts	NOTE (1)																I*
Air cleaner filter	NOTE (2)						[R]										[R]
EVAP vapor lines							I*										I*
Fuel lines							I*										I*
Fuel filter*	NOTE (3)																MA-16
Engine coolant	NOTE (4)																MA-16
Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	MA-14
Engine oil filter (Use part No. 15208-65F00 or equivalent.)		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	MA-17
Spark plugs (PLATINUM-TIPPED type)	NOTE (5)															[R]	MA-18

NOTE:

- (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.
 - (2) If operating mainly in dusty conditions, more frequent maintenance may be required.
 - (3) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.
 - (4) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.
 - (5) Original equipment platinum-tipped plug should be replaced at 60,000 miles (96,000 km). Conventional spark plugs can be used but should be replaced at 30,000 miles (48,000 km) intervals.
- ★ Maintenance items and intervals with "*" are recommended by INFINITI for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

PERIODIC MAINTENANCE

Schedule 1 (Cont'd)

CHASSIS AND BODY MAINTENANCE

NCA0004S0102

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. L = Lubricate.

MAINTENANCE OPERATION	MAINTENANCE INTERVAL														Reference Section - Page or Content Title		
	3.75 (6)	7.5 (12)	11.25 (18)	15 (24)	18.75 (30)	22.5 (36)	26.25 (42)	30 (48)	33.75 (54)	37.5 (60)	41.25 (66)	45 (72)	48.75 (78)	52.5 (84)		56.25 (90)	60 (96)
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000) Months																
Brake lines & cables				I				I									MA-24
Brake pads & rotors		I		I				I					I				MA-24
Manual transmission oil or automatic transmission fluid	NOTE (1)			I				I					I				MA-22, 23
Steering gear & linkage, axle & suspension parts		I		I				I					I				MA-25
Front drive shaft boots		I		I				I					I				AX - Drive Shaft
Exhaust system		I		I				I					I				MA-22
Air bag system	NOTE (2)																RS - Maintenance Items
Ventilation air filter		I		R				R					I				HA - Service Procedures

NOTE:

- (1) If towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil (exc. LSD) at every 30,000 miles (48,000 km) or 24 months, and change LSD gear oil every 15,000 miles (24,000 km) or 12 months.
- (2) Inspect the air bag system 10 years after the date of manufacture noted on the FMVSS certification label.
- (3) Refer to "Front Suspension Parts" and "Rear Suspension Parts" in SU section, "Front Axle Parts" and "Rear Axle Parts" in AX section.

PERIODIC MAINTENANCE

Schedule 2

Schedule 2

NCMA0004S02

NCMA0004S0201

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

EMISSION CONTROL SYSTEM MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. []: At the mileage intervals only

MAINTENANCE OPERATION	Miles x 1,000 (km x 1,000) Months	MAINTENANCE INTERVAL								Reference Section - Page or - Content Title		
		7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48			
Perform at number of miles, kilometers or months, whichever comes first.												
Drive belts	NOTE (1)										I*	MA-13
Air cleaner filter					[R]						[R]	MA-17
EVAP vapor lines					I*						I*	MA-21
Fuel lines					I*						I*	MA-16
Fuel filter*	NOTE (2)											MA-16
Engine coolant	NOTE (3)										R*	MA-14
Engine oil		R	R	R	R	R	R	R	R	R	R	MA-17
Engine oil filter (Use part No. 15208-65F00 or equivalent.)		R	R	R	R	R	R	R	R	R	R	MA-18
Spark plugs (PLATINUM-TIPPED type)	NOTE (4)										[R]	MA-19

NOTE:

- (1) After 60,000 miles (96,000 km) or 48 months, inspect every 15,000 miles (24,000 km) or 12 months.
- (2) If vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the filters might become clogged. In such an event, replace them immediately.
- (3) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.
- (4) Original equipment platinum-tipped plug should be replaced at 60,000 miles (96,000 km). Conventional spark plugs can be used but should be replaced at 30,000 miles (48,000 km) intervals.

★ Maintenance items and intervals with "*" are recommended by INFINITI for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

PERIODIC MAINTENANCE

Schedule 2 (Cont'd)

NCMA0004S0202

CHASSIS AND BODY MAINTENANCE

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary. L = Lubricate.

MAINTENANCE OPERATION	Miles x 1,000 (km x 1,000) Months	MAINTENANCE INTERVAL								Reference Section - Page or - Content Title
		7.5 (12) 6	15 (24) 12	22.5 (36) 18	30 (48) 24	37.5 (60) 30	45 (72) 36	52.5 (84) 42	60 (96) 48	
Perform at number of miles, kilometers or months, whichever comes first.										
Brake lines & cables		I	I		I		I			MA-24
Brake pads & rotors			I		I		I			MA-24
Manual transmission oil or automatic transmission fluid			I		I		I			MA-22, 23
Steering gear & linkage, axle & suspension parts					I					MA-25 NOTE (2)
Front drive shaft boots			I		I		I			AX - Drive Shaft
Exhaust system					I					MA-22
Air bag system	NOTE (1)									RS - Maintenance Item
Ventilation air filter			R		R		R			HA - Service Procedures

NOTE:

- (1) Inspect the air bag system 10 years after the date of manufacture noted on the FMVSS certification label.
- (2) Refer to "Front Suspension Parts" and "Rear Suspension Parts" in SU section, "Front Axle Parts" and "Rear Axle Parts" in AX section.

RECOMMENDED FLUIDS AND LUBRICANTS

Fluids and Lubricants

Fluids and Lubricants


NCMA0005S01

		Capacity (Approximate)			Recommended Fluids/Lubricants
		US measure	Imp measure	Liter	
Engine oil Drain and refill	With oil filter change	3-5/8 qt	3 qt	3.4	<ul style="list-style-type: none"> • API Certification Mark*1 • API grade SG/SH, Energy Conserving II or API grade SJ, Energy Conserving*1 • ILSAC grade GF-II*1
	Without oil filter change	3-3/8 qt	2-7/8 qt	3.2	
Dry engine (engine overhaul)		3-7/8 qt	3-1/8 qt	3.6	
Cooling system (With reservoir)	MT	6-1/2 qt	5-1/2 qt	6.2	Genuine Nissan Anti-freeze coolant or equivalent
	AT	6-1/2 qt	5-1/2 qt	6.2	
Manual transmission gear oil	RS5F32A	7-5/8 - 8 pt	6-3/8 - 6-3/4 pt	3.6 - 3.8	API GL-4, Viscosity SAE 80W-90 only
	RS5F32V	7-7/8 - 8-1/4 pt	6-1/2 - 6-7/8 pt	3.7 - 3.9	
Automatic transmission fluid	RE4F03A/V	7-3/8 qt	6-1/8 qt	7.0	Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada)*2
Power steering fluid		—	—	—	Type DEXRON™ III or equivalent
Brake and clutch fluid		—	—	—	Genuine Nissan Brake Fluid*3 or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease		—	—	—	NLGI No. 2 (Lithium soap base)

*1: For further details, see "SAE Viscosity Number".

*2: Dexron™ III/Mercon™ or equivalent may also be used. Outside the continental United States and Alaska contact an INFINITI dealership for more information regarding suitable fluids, including recommended brand(s) of Dexron™ III/Mercon™ Automatic Transmission Fluid.

*3: Available in mainland U.S.A. through your INFINITI dealer.



SAE Viscosity Number GASOLINE ENGINE OIL

NCMA0005S02

NCMA0005S0201

SAE 5W-30 viscosity oil is preferred for all temperatures. SAE 10W-30 viscosity oil may be used if the ambient temperature is above -18°C (0°F).

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

RECOMMENDED FLUIDS AND LUBRICANTS

Anti-freeze Coolant Mixture Ratio

Outside temperature down to		Anti-freeze	Demineralized water or distilled water
°C	°F		
-35	-30	50%	50%

SMA947CA

Anti-freeze Coolant Mixture Ratio

NCMA0005S03

The engine cooling system is filled at the factory with a high-quality, year-round, anti-freeze coolant solution. The anti-freeze solution contains rust and corrosion inhibitors. Therefore, additional cooling system additives are not necessary.

CAUTION:

When adding or replacing coolant, be sure to use only Genuine Nissan anti-freeze coolant or equivalent with the proper mixture ratio of 50% anti-freeze and 50% demineralized water/distilled water.


Other types of coolant solutions may damage your cooling system.

ENGINE MAINTENANCE

Checking Drive Belts

Checking Drive Belts

NCMA0006S01



1. Inspect belt for cracks, fraying, wear and oil. If necessary, replace.
2. Inspect drive belt deflection or tension at a point on the belt midway between pulleys. Check belt tension using belt tension gauge (BT3373-F or equivalent).
 - Inspect drive belt deflection or tension when engine is cold. Adjust if belt deflection exceeds the limit or if belt tension is not within specifications.
 - Belt tension can also be checked at other points on the belt.

DRIVE BELT DEFLECTION AND TENSION

		Deflection adjustment Unit: mm (in)			Tension adjustment *1 Unit: N (kg, lb)		
		Used belt		New belt	Used belt		New belt
		Limit	After adjustment		Limit	After adjustment	
Generator	With air conditioner compressor	11.5 - 12.5 (0.453 - 0.492)	7 - 8 (0.28 - 0.31)	6.5 - 7.5 (0.256 - 0.295)	324 (33, 75)	686 - 736 (70 - 75, 155 - 165)	755 - 853 (77 - 87, 170 - 190)
	Without air conditioner compressor	12 - 13 (0.47 - 0.51)	8 - 9 (0.31 - 0.35)	7 - 8 (0.28 - 0.31)	294 (30, 65)	549 - 647 (56 - 66, 125 - 145)	677 - 755 (69 - 77, 150 - 170)
Power steering oil pump		6 - 7 (0.24 - 0.28)	4 - 5 (0.16 - 0.20)	3.5 - 4.5 (0.138 - 0.177)	294 (30, 65)	549 - 647 (56 - 66, 125 - 145)	677 - 755 (69 - 77, 150 - 170)
Applied pushing force		98 N (10 kg, 22 lb)			—		

*1: If the belt tension gauge cannot be installed at check points shown, check belt tension at a different location on the belt.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

AMA047

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ENGINE MAINTENANCE

Changing Engine Coolant

Changing Engine Coolant

NCMA0006S02




WARNING:

To avoid the danger of being scalded, never change the coolant when the engine is hot.

—DRAINING ENGINE COOLANT—

NCMA0006S0201

1. Set air conditioning system as follows to prevent coolant from remaining in the system.
 - a. Turn ignition switch "ON" and set temperature controller to maximum hot position.
 - b. Wait 10 seconds before turning ignition switch "OFF".
2. Open radiator drain plug at the bottom of radiator and remove radiator cap.
3. Remove reservoir tank, drain coolant, then clean reservoir tank. Install it temporarily.
 - Be careful not to allow coolant to contact drive belts.




4. Remove cylinder block drain plug and air relief plug.
5. Check drained coolant for contaminants such as rust, corrosion or discoloration. If contaminated, flush engine cooling system. Refer to "—FLUSHING COOLING SYSTEM—", MA-16.

—REFILLING ENGINE COOLANT—

NCMA0006S0202

1. Install reservoir tank, radiator drain plug, and cylinder block drain plug.
 - **Apply sealant to the thread of cylinder block drain plug.**
 ☞ : 34.3 - 44.1 N·m (3.5 - 4.5 kg·m, 25 - 33 ft·lb)



2. Fill radiator slowly with coolant until coolant spills from the air relief plug, then install air relief plug.
3. Fill radiator and reservoir tank to specified level as soon as coolant spills out without bubbles.

Air relief plug:

☞ : 7.2 - 9.8 N·m (0.73 - 1.0 kg·m, 63.4 - 86.8 in·lb)

- Use genuine Nissan antifreeze coolant or equivalent mixed with water (distilled or demineralized).
- **Pour coolant through coolant filler neck slowly to allow air in system to escape.**


Refer to "RECOMMENDED FLUIDS AND LUBRICANTS", MA-12.

Coolant capacity (Without reservoir tank):

6.2 ℓ (6-1/2 US qt, 5-1/2 Imp qt)

Reservoir tank capacity (for MAX level):

0.7 ℓ (3/4 US qt, 5/8 Imp qt)



4. Warm up engine to normal operating temperature without radiator cap installed.
5. Run engine at 2,500 rpm for 10 seconds and return to idle speed.

- Repeat two or three times.

Watch coolant temperature gauge so as not to overheat the engine.

6. Stop engine and cool it down.
 - Cool down using a fan to reduce the time.
 - If necessary, refill radiator up to filler neck with coolant.
7. Refill reservoir tank to Max line with coolant.
8. Repeat step 5 through step 7 two or more times with radiator cap installed until coolant level no longer drops.
9. Check cooling system for leaks with engine running.
10. Warm up engine, and check for sound of coolant flow while running engine from idle up to 3,000 rpm with heater temperature control set at several positions between COOL and HOT.
 - Sound may be noticeable at heater water cock.
11. If sound is heard, bleed air from cooling system by repeating steps 5 through 7 until coolant level no longer drops.

ENGINE MAINTENANCE


Changing Engine Coolant (Cont'd)

- Clean excess coolant from engine.

—FLUSHING COOLING SYSTEM—

NCMA0006S0203


1. Open air relief plug.
2. Fill radiator with water until water spills from the air relief hole, then close air relief plug. Fill radiator and reservoir tank with water and reinstall radiator cap.
3. Run engine and warm it up to normal operating temperature.
4. Rev engine two or three times under no-load.
5. Stop engine and wait until it cools down.
6. Drain water.
7. Repeat steps 1 through 6 until clear water begins to drain from radiator.



Checking Fuel Lines

NCMA0006S03

Inspect fuel lines and tank for improper attachment, leaks, cracks, damage, loose connections, chafing or deterioration. If necessary, repair or replace faulty parts.




CAUTION:

Tighten high-pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end.

Tightening torque specifications are the same for all rubber hose clamps.

Ensure that screw does not contact adjacent parts.



Changing Fuel Filter

NCMA0006S04

WARNING:

Before removing fuel filter, release fuel pressure from fuel line.


WITH CONSULT

NCMA0006S0401

1. Start engine.
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode to release fuel pressure to zero.
3. After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
4. Turn ignition switch "OFF".

ENGINE MAINTENANCE

Changing Fuel Filter (Cont'd)




5. Loosen fuel hose clamps.
6. Replace fuel filter.
 - **Be careful not to spill fuel over engine compartment. Place a shop towel to absorb fuel.**
 - **Use a high-pressure type fuel filter. Do not use a synthetic resinous fuel filter.**
 - **When tightening fuel hose clamps, refer to "Checking Fuel Lines".**

GI

MA

EM

LC



⊗ WITHOUT CONSULT

NCMA0006S0402


1. Remove fuel pump fuse.
2. Start engine.
3. After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
4. Turn ignition switch "OFF" and install fuel pump fuse.

EC

FE

CL

MT



5. Loosen fuel hose clamps.
6. Replace fuel filter.
 - **Be careful not to spill fuel over engine compartment. Place a shop towel to absorb fuel.**
 - **Use a high-pressure type fuel filter. Do not use a synthetic resinous fuel filter.**
 - **When tightening fuel hose clamps, refer to "Checking Fuel Lines".**

AT

AX

SU

BR

Changing Air Cleaner Filter

NCMA0006S05

VISCOUS PAPER TYPE

NCMA0006S0501

The viscous paper type filter does not need cleaning.

ST

RS

BT

HA

SC

NCMA0006S06

Changing Engine Oil


WARNING:

- **Be careful not to burn yourself, as the engine oil is hot.**
- **Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.**

EL

IDX

1. Warm up engine, and check for oil leakage from engine components.
2. Stop engine.
3. Remove drain plug and oil filler cap.



ENGINE MAINTENANCE

Changing Engine Oil (Cont'd)

4. Drain oil and refill with new engine oil.

Oil specification and viscosity

- API Certification Mark
- API grade SG/SH, Energy Conserving II or API grade SJ, Energy Conserving
- ILSAC grade GF-II
- See "RECOMMENDED FLUIDS AND LUBRICANTS", MA-11.



Oil capacity (Approximate):

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	3.4 (3-5/8, 3)
	Without oil filter change	3.2 (3-3/8, 2-7/8)
Dry engine (engine overhaul)		3.6 (3-7/8, 3-1/8)

CAUTION:

- Be sure to clean drain plug and install with new washer.
Oil pan drain plug:
 : 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)
 - The refill capacity depends on the oil temperature and drain time. Use these specifications for reference only. Always use the dipstick to determine when the proper amount of oil is in the engine.
5. Warm up engine and check area around drain plug and oil filter for oil leakage.
 6. Stop engine.
 7. Check oil level.



Changing Oil Filter

NCMA0006S07

1. Remove oil filter with Tool.


WARNING:


Be careful not to burn yourself, as the engine and engine oil are hot.

The filter is a full-flow cartridge type and is provided with a relief valve.

Refer to LC section ("Oil Filter", "ENGINE LUBRICATION SYSTEM").

2. Clean oil filter mounting surface on cylinder block. Coat rubber seal of new oil filter with engine oil.






3. Screw in the oil filter until a slight resistance is felt, then tighten an additional 2/3 turn.
4. Add engine oil.


Refer to Changing Engine Oil.

- Clean excess oil from engine.



Changing Spark Plugs (Platinum-tipped type)

1. Disconnect ignition wires from spark plugs at boot. Do not pull on the wire.



2. Remove spark plugs with spark plug socket.

Spark plug:

Standard type	PFR5B-11
Cold type	PFR6B-11 PFR7B-11


Use standard type spark plug for normal condition.

The hot type spark plug is suitable when fouling occurs with the standard type spark plug under conditions such as:

- frequent engine starts
- low ambient temperatures

The cold type spark plug is suitable when spark knock occurs with the standard type spark plug under conditions such as:

- extended highway driving
- frequent high engine revolution



- Do not use a wire brush for cleaning.
- If plug tip is covered with carbon, spark plug cleaner may be used.

Cleaner air pressure:

Less than 588 kPa (6 kg/cm², 85 psi)


Cleaning time:

Less than 20 seconds

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ENGINE MAINTENANCE

Changing Spark Plugs (Platinum-tipped type) (Cont'd)




- Checking and adjusting plug gap is not required between change intervals.

3. Install spark plugs. Reconnect ignition wires according to numbers indicated on them.

Spark plug:

☐ : 20 - 29 N·m (2.0 - 3.0 kg·m, 14 - 22 ft·lb)



Changing Spark Plugs (Conventional type)

1. Disconnect ignition wires from spark plugs at boot. Do not pull on the wire. NCMA0006S10

2. Remove spark plugs with spark plug socket.

Spark plug:

Standard type	BKR6E
Hot type	BKR5E
Cold type	BKR7E


Use standard type spark plug for normal condition.

The hot type spark plug is suitable when fouling occurs with the standard type spark plug under conditions such as:

- frequent engine starts
- low ambient temperatures


The cold type spark plug is suitable when spark knock occurs with the standard type spark plug under conditions such as:

- extended highway driving
- frequent high engine revolution



ENGINE MAINTENANCE

Changing Spark Plugs (Conventional type) (Cont'd)



3. Check plug gap of each new spark plug.
Gap: 0.8 - 0.9 mm (0.031 - 0.035 in)
- Use a wire brush for cleaning, if necessary.
4. Install spark plugs. Reconnect ignition wires according to numbers indicated on them.

Spark plug:




: 20 - 29 N·m (2.0 - 3.0 kg-m, 14 - 22 ft-lb)

Checking EVAP Vapor Lines

NCMA0006509

1. Visually inspect EVAP vapor lines for improper attachment, cracks, damage, loose connections, chafing or deterioration.
2. Inspect vacuum relief valve of fuel tank filler cap for clogging, sticking, etc.

Refer to EC section ("EVAPORATIVE EMISSION SYSTEM").



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

CHASSIS AND BODY MAINTENANCE


Checking Exhaust System



Checking Exhaust System

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage, loose connections, chafing or deterioration.


NCMA0007S01



Checking Clutch Fluid Level and Leaks

If fluid level is extremely low, check clutch system for leaks.

NCMA0007S02



Checking M/T Oil


- Check that oil is not leaking from transaxle or around it.
- Remove speedometer pinion and check that the oil level L at vehicle rear side is within specification.

NCMA0007S03

Specified oil level (Dimension L):

RS5F32A 40 - 45 mm (1.57 - 1.77 in)

RS5F32V 34 - 40 mm (1.34 - 1.57 in)



Changing M/T Oil

1. Drain oil from drain plug and refill with new gear oil.
2. Check oil level. (Refer to "Checking M/T Oil".)

NCMA0007S04

Oil grade:

API GL-4

Viscosity:

See "RECOMMENDED FLUIDS AND LUBRICANTS", MA-11.

Capacity:


RS5F32A 3.6 - 3.8 l (7-5/8 - 8 US pt, 6-3/8 - 6-3/4 Imp pt)

RS5F32V 3.7 - 3.9 l (7-7/8 - 8-1/4 US pt, 6-1/2 - 6-7/8 Imp pt)

Drain plug:

: 25 - 34 N·m (2.5 - 3.5 kg·m, 18 - 25 ft·lb)

NCMA0007506



Checking A/T Fluid


1. Warm up engine.
2. Check for fluid leakage.
3. Before driving, fluid level can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on dipstick.
 - a. Park vehicle on level surface and set parking brake.
 - b. Start engine and move selector lever through each gear position. Leave selector lever in "P" position.
 - c. Check fluid level with engine idling.
 - d. Remove dipstick and note reading. If level is at low side of either range, and fluid to the charging pipe.
 - e. Re-insert dipstick into charging pipe as far as it will go.
 - f. Remove dipstick and note reading. If reading is at low side of range, add fluid to the charging pipe.

Do not overfill.

4. Drive vehicle for approximately 5 minutes in urban areas.
5. Re-check fluid level at fluid temperatures of 50 to 80°C (122 to 176°F) using "HOT" range on dipstick.



6. Check fluid condition.
 - If fluid is very dark or smells burned, refer to AT section for checking operation of A/T. Flush cooling system after repair of A/T.
 - If A/T fluid contains frictional material (clutches, bands, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of A/T. Refer to LC section ("Radiator", "ENGINE COOLING SYSTEM").



Changing A/T Fluid

NCMA0007507

1. Warm up A/T fluid.
2. Stop engine.
3. Drain A/T fluid from drain plug and refill with new A/T fluid. Always refill same volume with drained fluid.

Fluid grade:

Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada). Refer to "RECOMMENDED FLUIDS AND LUBRICANTS", MA-11.

Fluid capacity (With torque converter):

7.0 l (7-3/8 US qt, 6-1/8 Imp qt)

Drain plug:

: 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)

4. Run engine at idle speed for five minutes.
5. Check fluid level and condition. Refer to "Checking A/T Fluid". If fluid is still dirty, repeat steps 2 through 5.

CHASSIS AND BODY MAINTENANCE

Balancing Wheels


Balancing Wheels

NCMA0007S14

Adjust wheel balance using the road wheel center.

Wheel balance (Maximum allowable unbalance):

Refer to SDS, MA-27.




Tire Rotation

NCMA0007S15

- After rotating the tires, adjust the tire pressure.
- Retighten the wheel nuts after the aluminum wheel has been run for the first 1,000 km (600 miles). (also in cases of a flat tire, etc.)

Wheel nuts:


: 118 - 147 N·m (12 - 15 kg·m, 87 - 108 ft·lb)



Checking Brake Fluid Level and Leaks

NCMA0007S16


If fluid level is extremely low, check brake system for leaks.



Checking Brake Lines and Cables

NCMA0007S17

Check brake fluid lines and parking brake cables for improper attachment, leaks, chafing, abrasions and deterioration.



Checking Disc Brake

ROTOR

NCMA0007S18

NCMA0007S1801

Check condition and thickness.

Standard thickness:


Front 22 mm (0.87 in)

Rear 9 mm (0.35 in)

Minimum thickness:

Front 20 mm (0.79 in)

Rear 8 mm (0.31 in)



CALIPER
Check for leakage.


NCMA0007S1802

GI

MA

EM

LC



PAD
Check wear or damage.
Standard thickness:
Front 11 mm (0.43 in)
Rear 10 mm (0.39 in)
Minimum thickness:
Front 2 mm (0.08 in)
Rear 1.5 mm (0.0059 in)


NCMA0007S1803

EC

FE

CL

MT



Checking Steering Gear and Linkage

NCMA0007S20

AT

- STEERING GEAR**
- Check gear housing and boots for looseness, damage and grease leakage.
 - Check connection with steering column for looseness.

NCMA0007S2001


AX

- STEERING LINKAGE**
- Check ball joint, dust cover and other component parts for looseness, wear, damage and grease leakage.

NCMA0007S2002

SU

BR



Checking Power Steering Fluid and Lines

NCMA0007S21

ST

- CHECKING FLUID LEVEL**
- Check fluid level with engine off.
 - Use the correct range of the tank depending on the fluid temperature. Use "HOT" range at fluid temperatures of 50 to 80°C (122 to 176°F). Use "COLD" range at fluid temperatures of 0 to 30°C (32 to 86°F).

NCMA0007S2101

RS

BT

- CAUTION:**
- Do not overfill.
 - Recommended fluid is Automatic Transmission Fluid type DEXRON™III or equivalent.

NCMA0007S2102


HA

- CHECKING LINES**
- Check lines for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.
 - Check rack boots for accumulation of power steering fluid.

NCMA0007S2102

SC

EL




IDX

CHASSIS AND BODY MAINTENANCE

Lubricating Locks, Hinges and Hood Latches

Lubricating Locks, Hinges and Hood Latches

NCMA0007S22



SMA913C

Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters

NCMA0007S23

CAUTION:


- After any collision, inspect all seat belt assemblies, including retractors and other attached hardware (i.e. guide rail set). Nissan recommends to replace all seat belt assemblies in use during a collision, unless not damaged and properly operating after minor collision. Also inspect seat belt assemblies not in use during a collision, and replace if damaged or improperly operating. Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision where the driver and passenger air bags are deployed.
- If any component of seat belt assembly is questionable, do not repair. Replace as seat belt assembly.
- If webbing is cut, frayed, or damaged, replace belt assembly.
- Never oil tongue and buckle.
- Use a genuine seat belt assembly.

For details, refer to "Seat Belt Inspection", "SEAT BELTS" in RS section.

Anchor bolt

43 - 55 (4.4 - 5.6, 32 - 41)

: N·m (kg·m, ft·lb)



SMA024D

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Maintenance

Engine Maintenance

NCMA0008

DRIVE BELT DEFLECTION AND TENSION

NCMA0008S01

		Deflection adjustment Unit: mm (in)			Tension adjustment *1 Unit: N (kg, lb)		
		Used belt		New belt	Used belt		New belt
		Limit	After adjustment		Limit	After adjustment	
Generator	With air conditioner compressor	11.5 - 12.5 (0.453 - 0.492)	7 - 8 (0.28 - 0.31)	6.5 - 7.5 (0.256 - 0.295)	324 (33, 75)	686 - 736 (70 - 75, 155 - 165)	755 - 853 (77 - 87, 170 - 190)
	Without air conditioner compressor	12 - 13 (0.47 - 0.51)	8 - 9 (0.31 - 0.35)	7 - 8 (0.28 - 0.31)	294 (30, 65)	549 - 647 (56 - 66, 125 - 145)	677 - 755 (69 - 77, 150 - 170)
Power steering oil pump		6 - 7 (0.24 - 0.28)	4 - 5 (0.16 - 0.20)	3.5 - 4.5 (0.138 - 0.177)	294 (30, 65)	549 - 647 (56 - 66, 125 - 145)	677 - 755 (69 - 77, 150 - 170)
Applied pushing force		98 N (10 kg, 22 lb)			—		

*1: If the belt tension gauge cannot be installed at check points, check belt tension at a different location on the belt.

SPARK PLUG TYPE

NCMA0008S02

Type		Platinum-tipped type	Conventional type
		Standard	PFR5B-11
Hot		—	BKR5E
	Cold	PFR6B-11 PFR7B-11	BKR7E
Plug gap		—	0.8 - 0.9 mm (0.031 - 0.035 in)

Chassis and Body Maintenance

NCMA0009

WHEEL BALANCE

NCMA0009S01

Maximum allowable unbalance	Dynamic (At rim flange) g (oz)	10 (0.35) (one side)
	Static g (oz)	20 (0.71)